



Technical Guidance

Technical Guidance Note
AWPT H1/06/07 on:

Personal Fall Protection in Aerial Work Platforms

- Boom Supported Work Platforms (Boom Lifts) ANSI A92.5 and Vehicle-Mounted and Towable Work Platforms ANSI A92.2

OSHA regulations require the occupants of a boom lift to wear personal fall protection equipment while in the platform. When working from a boom type Aerial Work Platform (AWP), it is strongly recommended that a full body harness with an adjustable lanyard be used to provide work restraint. The lanyard should be adjusted to be as short as possible (and may have a shock absorbing section if permitted by the AWP manufacturer).

This would include:
Boom-Supported Elevating Work Platforms ANSI A92.5
Vehicle-Mounted Elevating and Rotating Aerial Devices ANSI A92.2.



- Self Propelled and Manually Propelled Elevating Work Platforms (Scissor Lifts and Vertical Lifts) ANSI A92.6 and A92.3

It is not normally necessary for personnel working from Self Propelled and Manually Propelled Elevating Work Platforms (e.g. scissor lifts and vertical lifts) to wear personal fall protection equipment, except when the manufacturer recommends the use of, or requires the use of, personal fall protection equipment.

This would include:
Self Propelled Elevating Work Platforms ANSI A92.6
Manually Propelled Elevating Work Platforms ANSI A92.3.

The need for a personal fall protection system will be the result of a job specific risk analysis undertaken prior to work starting and taking into consideration the manufacturer's operator's instructions as found in the operator's manual.

More details see overleaf or

www.awpt.org



SCAFFOLD
INDUSTRY
ASSOCIATION **SIA**
The Voice of the Scaffold and Access Industry

The ANSI standard for Boom-Supported Elevating Work Platforms (A92.5) and the Canadian standard for Boom-Supported Elevating Work Platforms (CSA B354.4) require that all personnel in the platform wear fall protection devices at all times. The OSHA regulation for aerial lifts (CFR 1926.453) requires the use of a full body harness when working from an aerial work platform. The full body harness should be attached, via a lanyard, to a lanyard anchorage point.

There are no current requirements by ANSI, CSA or OSHA requiring personnel to wear a fall protection device on scissor lifts or vertical masts (machines covered under the ANSI standards A92.6 and A92.3 and the CSA standard B354.2).

This guidance note was issued by AWPT Inc., a subsidiary of the International Powered Access Federation (IPAF) in June 2007. It was produced in association with the Scaffold Industry Association which fully endorses its recommendations.

AWPT is the North American subsidiary of IPAF, the organization that promotes the safe and effective use of powered access equipment worldwide. AWPT training complies with OSHA requirements and is based on IPAF training which is certified as conforming to the international standard ISO 18878. AWPT issues the PAL Card (Powered Access Licensed-Registration) to people who successfully complete a training course on powered access equipment at an approved training center. More than 80,000 PAL Cards are awarded each year through over 330 approved training centers worldwide. The PAL Card is recognized by the SIA as proof of training in the use of aerial work platforms and mast climbing work platforms.

www.awpt.org

For information about AWPT's full range of training programs for all kinds of AWP's visit www.awpt.org



AWPT Training complies with OSHA requirements.

AWPT Inc, 225 Placid Drive, Schenectady, NY 12303, USA.

Tel: +1 518 280 2486 Fax: +1 518 689 6800

mail@awpt.org www.awpt.org

A subsidiary of IPAF

International Powered Access Federation

1 Moss End Business Village, Crooklands, Cumbria LA7 7NU, UK.

Tel: +44 (0)15395 62444 Fax: +44 (0)15395 64686

info@ipaf.org www.ipaf.org



The world authority in powered access